

Spis treści

Manometr M40T; 0-1,0bar; G1 8 (MANM40)	2
Manometr M40T; 0-2,5bar; G1 8 (425893)	3
Manometr M40T; 0-4bar MPa; G1 8 (446787)	4
Manometr M40T; 0-0,4MPa bar; M10x1 (988A7)	5
Manometr M40T; 0-10bar MPa; G1 8 (44399)	6
Manometr M40T; 0-1,0MPa bar; M10x1 (426911)	7
Manometr M40T; 0-12bar; G1 8 (455375)	8
Manometr M40T; gl; 0-10bar; G1 8 (438753)	9
Manometr M40R; gl; 0-60MPa; DN10; dławik (495773)	10



Manometr M40T; 0-1,0bar; G1/8"; **MANM40**



Manometr M40T; 0-2,5bar;
G1/8"; **425893**




Manometr M40T; 0-4bar/MPa;
G1/8"; **446787**



Manometr M40T; 0-0,4MPa/bar;
M10x1; **444F-988A7**



Manometr M40T; 0-10bar/MPa;
G1/8"; **44399**



Manometr M40T; 0-1,0MPa/bar;
M10x1; **426911**



Manometr M40T; 0-12bar; G1/8"
455375



Manometr M40T; gl; 0-10bar; G1/8"; **438753**



Manometr M40R; gl; 0-60MPa;
DN10; dławik; **495773**